



PARQUE DANCEFLOOR

Details

This Parque Dance Flooring system is the most popular type of dancefloor available. The color and pattern look great in any environment.

Product Specifications

- **Dimensions:** 1'x1' panel can be connected to make desired size
- **Weight:** 2lb per 1'x1' panel
- **Colour:** Imitation Oak Parque pattern

Important information

- No Walk technology – Ensures your floor stays put all throughout your event
- For indoor and outdoor use
- 100% waterproof

Installation Instructions

- The panels have two sides with female PowerLocks, and two sides with male PowerLocks. All files on any given installation should always have the female PowerLocks going in the same direction.
- Begin the installation by laying down your first panel in any one corner and pointing the female PowerLocks in the two directions that additional panels are to be added.
- Place the next panel so that the male PowerLock line up over the top of the female loops on the first panel. It's important to make sure that the female PowerLocks are facing exactly the same direction as the first panel.
- Gently step along the joint of the two panels. You will hear and feel the PowerLocks snap into place as you go.
- Once the two panels are joined, repeat steps one through three remembering to keep the female PowerLocks aligned until your floor is complete.
- Installation video: <https://www.youtube.com/watch?v=jhhulC505SE>